

Application Instructions

Reflexite® VC104 Curtain Grade PSA can be applied to trucks and trailers with new and old PVC curtains. Important: The Reflexite warranty is applicable to new curtains only.

Curtains

The performance of the adhesive will depend greatly on the curtain surface. Every curtain type should be assessed individually for suitability. Graphics printed by digital/screen/stencil technique and using clear coats or varnishes for additional durability need to be assessed for Reflexite® VC104 Curtain Grade PSA adhesion. Reflexite accepts no responsibility for poor adhesion to clear coat or pre-treated curtains. It is the applicator's responsibility to ensure that the curtain is suitable for application.

Tools Required

- Clean cloths
- Craft knife
- Squeegee with sleeve to avoid scratching the material
- Solvent cleaner: Isopropyl alcohol (IPA)
- Used curtains only: Abrasive pad

Application Temperature

To ensure proper adhesion between the tape and the cleaned curtain bonding materials must be applied when both curtain and tape temperature is between 15°C and 38°C. The temperature needs to be consistent for at least one hour after application. NB! It is recommended that Reflexite® VC104 Curtain Grade PSA is stored at temperatures between 18°C and 28°C.

Where to apply

It is recommended to position the tape minimum 15 cm above the buckles. Use the guidelines provided in Regulation ECE 104 to ensure that the tape is in general positioned correctly on the vehicle. Check www.ece104.com for more information.

Step 1: Initial Preparation

The tape can be applied either on a flat surface, or while tensioned on the trailer. If on a flat surface, lightly tension the curtain at either end ensuring that the curtain surface is flat. An example of how to do this is to place a weight at either end of the length of the curtain.

When applied on a trailer, position a board behind the curtain to ensure enough pressure can be applied to the tape when using the squeegee. This is done most easily by having at least two people to do the application.


It is recommended that the curtain is not over-tensioned during application.

Used Curtains:

Survey used curtain for suitability of application, avoiding application over tears, holes or repairs. NB! It is the applicator's responsibility to ensure that the curtain is suitable for application.

Step 2: Surface Cleaning

The purpose of cleaning the curtain is to remove any dirt or contamination. It is very important that the surface is free of dust and grease, and ideally the surface should be smooth. Use a clean cloth with isopropyl alcohol to wipe the surface in one direction only to avoid spreading contamination. With a dry clean cloth wipe away the cleaner before evaporation. Repeat this process until the surface is clean, i.e. when there is no visual dirt or contamination transfer onto the cloth. Ensure the surface is dry and the isopropyl alcohol has completely evaporated before commencing application.



Used Curtains:

An additional step is required for used curtains: After completing the above cleaning process, abrade the area with an abrasive pad, and clean again using a clean cloth with isopropyl alcohol.

Step 3: Alignment

Mark out a pencil line guide, or alternatively apply a strip of masking tape.

Step 4: Application

Tack the end of the tape onto the surface (20mm from the edge), peel back approximately 1 meter of the release liner and tack the tape in place using the squeegee. Repeat the process for the length of the vehicle. This will eliminate the build up of tension in the tape during the application process. Avoid touching the adhesive side of the tape.

After completing this process, apply pressure using a squeegee along the length of the tape, to remove any trapped air or wrinkles.

It is important to ensure that the edges of the tape have been properly adhered to the curtain.

Upon inspection of the application there should be no visual air bubbles. Prick out any bubbles with a pin or sharp blade and press down.

NB! All corners of the tape should be rounded using a pair of scissors or sharp blade. It is recommended that this is done before the tape is applied to the curtain. If a full contour marking is done, the corners of the tape can be overlapped.





Step 5: Bonding Time

The applied material should remain at temperatures between 15°C and 38°C for at least one hour after application. It is recommended that the vehicle is not moved and/or the curtain not folded or opened during this period.

The curtain should be folded in such a way, that the tape is on the outside and not folded in.

Step 6: After application

The tape has a transparent top clear polyester carrier attached to its surface which must be removed after the tape has been applied. When the application process is finished, care should be taken when rolling the curtain to ensure that no sharp folds or bends are present.



Care Instructions

Manual Washing:

Reflexite® VC104 Curtain Grade PSA can be washed manually by brush, cloth or sponge using water, soap or detergent followed by a clean water rinse.

Power Washing:

Automatic truck / car wash or standard high-pressure hand spray:

- Maximum pressure – 1200 PSI / 80 bar
- Maximum water / wash solution 60° C
- 40° Nozzle cone opening size should be used
- Cleaning wand or jets to be at no greater angle than 45 degrees from perpendicular to the marking surface
- Hold the cleaning jet a minimum of 60cm away from the material

When using cleaners, follow the manufacturer's recommendations for dilution. Thoroughly rinse after soaking vehicle.

Important: Do not use solvents to clean the tape, as they can adversely affect the product. If soap or detergent does not sufficiently clean the film, gently rub a cloth soaked in isopropyl alcohol to remove the stains.

IMPORTANT NOTICE

All Reflexite products are subject to careful quality control throughout the manufacturing process and are warranted to be of merchantable quality and free from manufacturing defects.

Published information concerning Reflexite products is based upon research, which the Company believes to be reliable although such information does not constitute a warranty.

Because of the variety of uses of Reflexite products and the continuing development of new applications, the purchaser should carefully consider the suitability and performance of the product for each intended use, and the purchaser shall assume all risks regarding such use.

All specifications are subject to change without prior notice.

Reflexite EMEA Conversion Centre

Unit 5, Cleaboy Business Park
Old Kilmeaden Road
Waterford
Ireland

Tel. +353 51 359400

Fax. +353 51 359459

www.reflexite.eu

Reflexite ® is a registered trademark of Reflexite Corporation, Avon CT, USA

Technical Publication EU-APP-10, Pub. October 2009

© 2009, Reflexite Europe